



Attention:

A. To avoid polluting your head and floor, please wear gloves provided and place some paper on floor.

B. Please go on in order in accordance with the following steps



01. Remove all cartridge from printer.



02. Power down printer, remove the power cable of printer.



03. Place CFS on the printer platform.



04. Open the printer's back lid.



05. Loose the tube of CFS.



06. Pull out the ink tube of printer.



07. Connecting CFS's tube with ink tube of printer.



08. Connect all 6 tube with ink tube of printer.



09. Insert Stopper into ink outlet of printer.



10. Finishing picture of back section.



11. Clamping 6 tube by clip provided and taping the gap of clip by tape.



12. Clamping and taping again below about 15cm of the first clip.





13. Bend the two clip and put them into the gap of printer.



14. Try to cover the back lid.



15. Try to open the front cover, check if it will jam with tube of CFS.



16. Pull out the data cord of printer.



17. Preparing solution card.



18. Insert data cord into solution card, then insert solution card into data socket of printer.



19. Pull out the cleaner solt.



20. Pull out the carriage of printhead.



21. Take out all printhead, prepare vacuum bottle provided.



22. Use vacuum bottle to draw out remain ink which in tube of printer.



23. Pour ink into CFS.



24. Drain the all ink of vacuum bottle.



25. Use vacuum bottle again to draw out remains air in the tube of printer.



26. Put back printhead in carriage.



27. Push back the printhead carriage.



28. Push back the cleaner slot.



29. Insert the ink cartridge into the cartridge slot.



30. Power on printer. Procedure finished.